
10
modem
19B
P-P Acc
RMS Vel
P-P Displ
14
16
64
22
24
26
18
20
29
28
Numeric zone Display
RMS VEL Level
31
58
56
12
30
Zone Display
LED
DownLoad to Other Storage Devices
60
32
34
PRINTER
Vib Coach (Tm)
36
38
42
40
44
Status
· Computer Terminal
· Web page
· Remote Site
66
Digital Storage
Adjustable Threshold
52
54
50
Alarm Unit
PLC/PC

Fig. 1